


Formatting the TrekStor
i.Beat run

Formatierung des TrekStor i.Beat run

 *Beim Formatieren werden ALLE Daten auf dem MP3-Player gelöscht.*

In diesem Abschnitt wird Ihnen erläutert, wie Sie Ihren MP3-Player unter Windows® 2000/XP/Vista, Mac® OS X ab 10.3 formatieren können.

Windows® 2000/XP/Vista

- a) Schließen Sie Ihren MP3-Player an einen USB-Anschluss Ihres Computers an.
- b) Sichern Sie alle wichtigen Daten des MP3-Players auf Ihrem Computer.
- c) Öffnen Sie den "ARBEITSPLATZ"/"COMPUTER" und klicken Sie mit der rechten Maustaste auf Ihren MP3-Player ("WECHSELDATENTRÄGER").
- d) Wählen Sie aus dem Kontextmenü den Punkt "FORMATIEREN..." aus.
- e) Wählen Sie im erscheinenden Dialogfenster unter "DATEISYSTEM" die Option "FAT32" aus.
- f) Klicken Sie auf die Schaltfläche "STARTEN", um die Formatierung durchzuführen.
- g) Bitte warten Sie bis die Formatierung abgeschlossen ist.

Mac® OS X ab 10.3

- a) Schließen Sie Ihren MP3-Player an einen USB-Anschluss Ihres Computers an.
- b) Sichern Sie alle wichtigen Daten des MP3-Players auf Ihrem Computer.
- c) Öffnen Sie über "FINDER" → "PROGRAMME" → "DIENSTPROGRAMME" das "FESTPLATTEN-DIENSTPROGRAMM".
- d) Klicken Sie auf den MP3-Player.
- e) Wählen Sie aus dem rechten Fenster die Option "LÖSCHEN" aus.
- f) Wählen Sie mithilfe der Drop-Down-Liste das Dateisystem "MS-DOS DATEISYSTEM" für Ihren MP3-Player aus.
- g) Klicken Sie auf die Schaltfläche "LÖSCHEN" und bestätigen Sie die anschließende Abfrage, um die Formatierung zu starten.
- h) Bitte warten Sie bis die Formatierung abgeschlossen ist. Die Formatierung des MP3-Players kann einige Zeit in Anspruch nehmen.

Formatting the TrekStor i.Beat run

 *Note: ALL the data on the MP3 player will be deleted when you format it.*

In this section you can find instructions on how to format your MP3 player using the operating systems Windows® 2000/XP/Vista, Mac® OS X from 10.3.

Windows® 2000/XP/Vista

- a) Connect your MP3 player to a USB port on your computer.
- b) Back up all the important data on your MP3 player onto your computer.
- c) Open "My COMPUTER"/"COMPUTER" and click your right mouse button on your MP3 player ("DEVICE WITH REMOVABLE STORAGE").
- d) Select "FORMAT..." from the context menu.
- e) Select the "FAT32" option under "FILE SYSTEM" from the dialog window that appears.
- f) Click on the "START" button to start formatting.
- g) Please wait until formatting has completed.

Mac® OS X from 10.3

- a) Connect your MP3 player to a USB port on your computer.
- b) Back up all the important data of your MP3 player on your computer.
- c) Open "DISK UTILITY" via "FINDER" → "PROGRAMS" → "UTILITIES".
- d) Click the MP3 player.
- e) From the right window, select the "DELETE" option and confirm the following query.
- f) Using the drop-down list, select the "MS-DOS FILE SYSTEM" for your MP3 player.
- g) Click the "DELETE" button to start formatting.
- h) Please wait patiently until formatting has completed. This can take some time.

Support

	Hotline	E-Mail	Language
AT	+49 431 - 24 89 45 70**	support.at@trekstor.de	German
BE	+49 431 - 24 89 45 80**	support.en@trekstor.de	English
CH	+49 431 - 24 89 45 73**	support.ch@trekstor.de	German
DE	01805 - TREKSTOR* 01805 - 87 35 78 67*	support.de@trekstor.de	German
ES	+49 431 - 24 89 45 76**	support.es@trekstor.de	Spanish
FR	+49 431 - 24 89 45 74**	support.fr@trekstor.de	French
HU	+49 431 - 24 89 45 79**	support.en@trekstor.de	English
IT	+49 431 - 24 89 45 75**	support.it@trekstor.de	Italian
LU	+49 431 - 24 89 45 72**	support.lu@trekstor.de	German, French
NL	+49 431 - 24 89 45 81**	support.en@trekstor.de	English
PL	+49 431 - 24 89 45 77**	support.pl@trekstor.de	Polish
PT	+49 431 - 24 89 45 78**	support.en@trekstor.de	English
UK	+49 431 - 24 89 45 71**	support.uk@trekstor.de	English
GR	+49 431 - 24 89 45 82**	support.en@trekstor.de	English
TR	+49 431 - 24 89 45 83**	support.en@trekstor.de	English
RU	+49 431 - 24 89 45 84**	support.en@trekstor.de	English
SE	+49 431 - 24 89 45 92**	support.en@trekstor.de	English
UA	+49 431 - 24 89 45 93**	support.en@trekstor.de	English
SI	+49 431 - 24 89 45 94**	support.en@trekstor.de	English
CA	+49 431 - 24 89 45 95** +49 431 - 24 89 45 96**	support.en@trekstor.de support.fr@trekstor.de	English French
Other Countries	+49 431 - 24 89 45 99**	support.en@trekstor.de	English

* 14 Cent/Min. aus dem deutschen Festnetz der DTAG,
ggf. andere Preise aus Mobilfunknetzen

** Please check with your local telephone provider for connection costs.

TrekStor GmbH & Co. KG

Kastanienallee 8-10 · D-64653 Lorsch · Germany

www.trekstor.de



BA-IBRUN-FORMAT-DE-EN-V1.10-090702